MULTIPLE 24V Electric/Battery Duette Blinds Set up

Most blinds come ready paired to the remote control but if you need to pair it yourself please see the instructions below:

Wake the blind and pair with the remote control

1. Complete this procedure **before fitting the blind**, as the <u>receiver can be inbuilt in the head rail</u> and **<u>not</u>** accessible once the blind is fitted. Please note **DO NOT** try to operate the blind until it is fitted.
2. Connect the blind to the power supply / transformer , plug the power supply / transformer to the mains – the blind may jog but if not do not worry continue

    (Item number 3 & 4 must be completed within 8 seconds of each other)

3. Press and hold the programme button on the receiver, you may need to use something like a paper clip - the blind will jog
4. Choose the required channel on the remote control, then press and hold the programme button on the rear of the remote - the blind will jog
5. The blind is paired with the remote control
6. Disconnect the power and fit the blind

Group Blinds

- Set the remote to the blind/channel you want to add to the group, press rear button on the remote until blind- the blind will jog , set the remote to the group channel required, press rear button **<u>very very briefly</u>** - the blind will jog
- Repeat as required

Re set Blind to factory setting

- Press and hold receiver button until blind jogs 3 times , The blind will need pairing back to the remote control again

My Position

- Select the blind required , Stop the blind at the required position and press and hold "My Button" for 5 seconds
- To delete - Select the blind required , press and hold the my button for 5 seconds

To reconnect the remote to the blind

- Hold up and down buttons simultaneously until blind jogs
- Complete

Alter Motor Direction

- Isolate the blind from any group it may be attached to
- Press and hold the up and down buttons **<u>simultaneously</u>** until the blind jogs once
- Press and hold the "my" button until the blind jogs once
- Press and hold the "my" button until the blind jogs twice (this takes the blind out of programme mode)
- Complete