

Neat Fit Measuring Guide

Please note that these blinds are only suitable for UPVC windows with an internal rubber seal between the glass and the bead.

Check your window or door is suitable.
Slide a knife between the glass and the seal as far as it will go.



Mark the knife to show how far it travelled behind the seal.
Measure the distance, it must be at least 10mm to accommodate the blinds.



Measure the glass between the bead in 3 places, across the top, middle and bottom. Do the same for the height of the glass. Choose the smallest dimension for both the width and the drop.

Decide on your preferred fabric and place your order.