

# SINGLE 24V Electric Duette Blind Set up

If you have chosen a Battery-Operated Blind please ensure you install the battery tube below the blind NOT above.

## Wake the blind and pair with the remote control

1. Complete this procedure **before fitting the blind**, as the receiver can be inbuilt in the head rail and **not** accessible once the blind is fitted. Please note **DO NOT** try to operate the blind until it is fitted.
2. Connect the blind to the power supply / transformer , plug the power supply / transformer to the mains – the blind may jog but if not do not worry continue

(Item number 3 & 4 must be completed within 8 seconds of each other)

3. Press and hold the programme button on the receiver (can be in the head rail), you may need to use something like a paper clip - the blind will jog
4. Press and hold the programme button on the rear of the remote - the blind will jog
5. The blind is paired with the remote control
6. Disconnect the power and fit the blind

## Re set Blind to factory setting

- Press and hold receiver button until blind jogs 3 times , The blind will need pairing back to the remote control again

## My Position

- Stop the blind at the required position and press and hold “My Button” for 5 seconds
- To delete - Select the blind required , press and hold the my button for 5 seconds

## To reconnect the remote to the blind

- Hold up and down buttons simultaneously until blind jogs
- Complete

## Alter Motor Direction

- Isolate the blind from any group it may be attached to
- Press and hold the up and down buttons simultaneously until the blind jogs once
- Press and hold the “my” button until the blind jogs once
- Press and hold the “my” button until the blind jogs twice (this takes the blind out of programme mode)
- Complete