

Somfy Tilt & Lift Initial Set Up Guide

Please Note: If you have ordered multiple motorised blinds, it is important that you only wake one blind at a time in order to set up each blind individually.

Wake the Motor

In order to wake the motor you will need to connect the power source (battery pack/mains plug), the blind should jog once. You will now be able to test if the pre-set limits are suitable or if they need adjusted.

Testing/Adjusting the Upper Limit

Press the Up button on your remote – Blind will travel to the pre-set upper limit

If the pre-set limit is suitable, please move on to Testing/Adjusting the Lower limit.

If the Upper limit needs to be adjusted:

1. Press and Hold the Up and Down Buttons together for 5secs until the blind jogs once
2. Press the Up/Down buttons to move the Blind to your new desired upper position
3. Once you have the blind in the position you wish to set, press and hold the MY button until the blind jogs once

Testing/Adjusting the Lower Limit

Press the Down button on your remote – Blind will travel to pre-set lower limit

If this is suitable, please move on to Setting the MY/Favourite Position.

If the Lower limit needs to be adjusted:

1. Press and Hold the Up and Down Buttons together for 5secs until the blind jogs once
2. Press the Up/Down buttons to move the Blind to your new desired lower position
3. Once you have the blind in the position you wish to set, press and hold the MY button until the blind jogs once

Setting the MY/Favourite Position

Press either the Up/Down buttons so that the blind travels in the direction of your choice

1. Press MY to stop the blind at your desired intermediate position
2. Press and hold the MY button for approx. 5secs until the blind jogs once

Your Favourite Intermediate position has now been set

This blind has now completed its set up and is ready for use.

Should you be installing more than 1 motorised blind, you will need to disconnect the power to this blind in order to move on to the next.